





Exa[®] PACS|RIS

Feature Summary: Change Your Password


1. On the burger  menu, select the Konica Minolta logo.



2. In the **My Profile** dialog box, select **CHANGE PASSWORD**.

A screenshot of the 'My Profile' dialog box. The dialog has a dark blue header with the title 'My Profile' on the left and 'EXA Version 35.0.0-rc32' and 'UDI (01)00817100020193(10)35-00-000' on the right. The main content area contains various user settings: 'User Name' (afox), 'Name' (Aiden, MI, Fox, Suffix), 'Mobile Phone / Email' (Mobile Phone, Email), 'Default Device' (dropdown, Auto Open Dictation on Device checkbox), 'Default Location' (Applications Facility dropdown, Always Open Schedule Book in a New Tab checkbox), 'Rows to Display' (dropdown, Themes: default, Culture: English-US, Pin Burger Menu checkbox, Hide Worklist Icons checkbox), 'Bandwidth' (Select dropdown), 'Session Interval' (20 min (10-600)), and 'Default Scheduling' (Radiology radio button). On the right side, there is a large circular placeholder for an avatar with buttons 'Choose File', 'NO F...OSEN', and 'DELETE AVATAR'. At the bottom right, there are two buttons: 'SAVE' and 'CHANGE PASSWORD'. A mouse cursor is pointing at the 'CHANGE PASSWORD' button.

3. At the bottom of the dialog box, in the **Current Password** box, type your current password or the temporary password provided by your administrator.

A screenshot of a password change dialog box. It contains three input fields: 'Current Password' (filled with dots), 'New Password', and 'Confirm Password'. Below these fields is a blue button labeled 'SAVE PASSWORD'. At the bottom, there is a list of password requirements, each preceded by a radio button:

- Min password length: 12
- Max password length: 30
- Number of uppercase letters: 1
- Number of lowercase letters: 1
- Number of numerical characters: 1
- Number of special characters: 1

4. Type your new password twice, and then click **SAVE PASSWORD**.
Type a password that meets all requirements, as indicated by check marks.
8. Select **SAVE PASSWORD**.